



### BOARD VERSIONS

RTP Version: DNM - CTP, C67, C23, D5, R7, C74, C69, C70, C71, C72  
 CTP Version: DNM - C2, R1, C1, C3, D1, D2, D3, D4, U1, C23, D5, R7, C74, C69, C70, C71, C72  
 NT Version: DNM - C2, R1, C1, C3, D1, D2, D3, D4, U1, CTP, C67, R2, R3, R4, R26, C23, D5, R7, C74, C69, C70, C71, C72 - FUTURE MODEL

